

The Buildercost Import Form:

Import Cad Data

Alter Imported Quantity Match Alt Code to BCW Alt Code Print Non-Matching Alt Codes

Non-Matching Codes Delete a Non-Matching Alt Code Print Matching Alt Codes

Alt Code	Quantity	Description

Matching Codes Price List Templates Assembly Templates ⏪ ⏩ ⏴ ⏵

Alt Code	Quantity	Description
0000420	24.280	Footing 600x350w NS2
0000810	36.301	Concrete Slab 100mm NF 72
0001220	42.504	100 mm Concrete Drivetays per Sq/Me
0001430	25.760	110mm Brick Veneer 2.410h
0002740	24.000	External Wall Frame 2.4h 70x35 F5

Selected Client for Estimate - (the Target Job ID).

Job ID	Client Name
GARAGE	Double Brick Veneer Garage

2. Set Selected Job as Target Job ID Target Job ID: GARAGE

Create a New Client Record Clear All Codes

Create a New Assembly

1. Import Selected Cad Data

3. Upload Matching Codes

4. Go to the Estimate form Close and End